



Instructions

Chafers

Oblong Chafer

Includes:

- 1 water Pan
- 2 sterno holders
- 1 Lid

Round Chafer

Includes:

- 1 Water Pan
- 1 Sterno Holder
- 1 Lid

Options:

- Half Size 2" Deep Food Pans
- Full Size 2" Deep Food Pans
- Half Size 4" Deep Food Pans
- Full Size 4" Deep Food Pans
- Full Size round Food Pans

Operating Tips

1. Do not use anything but STERNO TYPE FUEL in the burner.
2. Never light the burner unit before putting liquid into the water pan. Low flame is sufficient to maintain proper heat.
3. Do not put unit on hot stove or an open flame.
4. Stainless steel food pans can be used for cooking. They can also be placed in the oven to keep food hot.
5. Chafing dish water pans should be filled 1 in deep with hot water. Check water pan when in use to insure sufficient water is contained at all times. DO NOT USE WITHOUT WATER.

Use of Sterno

1. Pry the lid off of Sterno and set Sterno container into the heat cup. Light Sterno and adjust lid of heat cup approximately ½ open.

Cleaning Instructions

1. Before returning chafing dish, scrape and wash food pans. Wash chafing dish in lukewarm water with mild detergent. NEVER USE HARSH ABRASIVES.